



Security Gateway Manual

SG-1100

© Copyright 2020 Rubicon Communications LLC

Oct 21, 2020

CONTENTS

1	Out of the Box	2
2	How-To Guides	20
3	References	55



This Quick Start Guide covers the first time connection procedures for the Netgate® SG-1100 Firewall Appliance and will provide the information needed to keep the appliance up and running.

Tip: Before getting started, we recommend downloading the [PDF version of the Product Manual](#) and the [PDF version of the pfSense Documentation](#) in case you lose Internet access.


OUT OF THE BOX

1.1 Getting Started

The basic firewall configuration begins with connecting the Netgate® appliance to the Internet. The Netgate appliance should be unplugged at this time.

Connect one end of an Ethernet cable to the WAN port (shown in the *Input and Output Ports* section) of the Netgate appliance. The other end of the same cable should be inserted into a port of the Cable or DSL modem. The modem provided by the ISP should have multiple LAN ports. Any port should work.

Next, connect one end of a second Ethernet cable to the LAN port (shown in the *Input and Output Ports* section) of the Netgate appliance. Connect the other end to the computer.



Warning: The default IP Address on the LAN subnet on the Netgate firewall is 192.168.1.1/24. The same subnet **cannot** be used on both WAN and LAN, so if the default IP address on the ISP-supplied modem is also 192.168.1.1/24, **disconnect the WAN** interface until the LAN interface on the firewall has been renumbered to a different subnet (like **192.168.2.1/24**) to avoid an IP Address conflict.

To change an interface IP address, choose option 2 from the Console Menu and walk through the steps to change it, or from the WebGUI, go through the Setup Wizard (opens at first boot, also found at **System -> Setup Wizard**) and change the IP address on Step 5. Complete the Wizard and save the changes.

1.2 Initial Configuration

Plug the power cable into the power port (shown in the *Input and Output Ports* section) to turn on the Netgate® Firewall. Allow 4 or 5 minutes to boot up completely.

Warning: If your DSL or Cable Modem has a default IP Address of 192.168.1.1, please disconnect the Ethernet cable from the WAN port on your SG-1100 Netgate Security Gateway before proceeding. You will need to change the default IP Address of the device during a later step in the configuration.

1. From the computer, log into the Web Interface

Open a web browser (Google Chrome in this example) and type in 192.168.1.1 on the address bar. Press Enter.



Fig. 1: Enter the Default LAN IP Address

2. A warning message may appear. If this message or similar message is encountered, it is safe to proceed. Click the **Advanced Button** and the click **Proceed to 192.168.1.1 (unsafe) to continue.**
3. At the **Sign In** page, enter the default pfSense username and password and click **Next.**
 - Default Username: **admin**
 - Default Password: **pfsense**

1.2.1 The Setup Wizard

The following steps will step through the Setup Wizard for the initial configuration of the firewall.

Note: Ignore the warning to reset the 'admin' account password. One of the steps in the Setup Wizard is to change the default password.

1. Click **Next** to start the Setup Wizard.
2. Click **Next** after you have read the information on Netgate Global Support.




Fig. 2: Click **Advanced** and then **Proceed to 192.168.1.1 (unsafe)**





Fig. 3: Click **Next**

3. On the General Information page, use the following as a guide to configure the firewall.

Hostname: Any desired name can be entered. For the purposes of this guide, the default hostname `pfSense` is used.

Domain: The default `localdomain` is used for the purposes of this tutorial.

DNS Servers: For purposes of this setup guide, use the Google public DNS servers (8.8.8.8 and 8.8.4.4).



The screenshot shows the pfSense web interface during the 'General Information' step of the setup wizard. The breadcrumb trail is 'Wizard / pfSense Setup / General Information'. A progress bar indicates 'Step 2 of 9'. The 'General Information' section contains the following fields and options:

- Hostname:** Input field containing 'pfSense'. Below it, an example is shown: 'EXAMPLE: myserver'.
- Domain:** Input field containing 'localdomain'. Below it, an example is shown: 'EXAMPLE: mydomain.com'.
- Primary DNS Server:** Input field containing '8.8.8.8'.
- Secondary DNS Server:** Input field containing '8.8.4.4'.
- Override DNS:** A checkbox that is checked. Below it, the text reads: 'Allow DNS servers to be overridden by DHCP/PPP on WAN'.

A blue 'Next' button with a right-pointing arrow is located at the bottom of the form.

Fig. 4: Type in the DNS Server information and Click **Next**

4. Use the following information for the Time Server Information page.

Time Server Hostname: Use the default pfSense time server address.

Timezone: Select the time zone for the location of the firewall. For this guide, the Timezone will be set to `America/Chicago` for US Central time.

5. The WAN interface is the Public IP address the network will use to communicate with the Internet. Use the following information for the WAN configuration page.


DHCP is the default and is the most common type of interface for home cable modems.

Default settings for the other items on this page should be acceptable for normal home users.

6. Configuring LAN IP Address & Subnet Mask. The default LAN IP address of `192.168.1.1` and subnet mask of `24` is usually sufficient.


Tip: If your DSL or Cable Modem has a default IP Address of `192.168.1.1`, change the IP Address of your SG-1100 Netgate Security Gateway to a different subnet, such as `192.168.2.1` with a subnet mask of `24` to avoid an IP Address conflict.

7. Change the **Admin Password**. Enter the same password in both fields.
8. Click **Reload** to save the configuration.



The screenshot shows the pfSense web interface. At the top, there is a navigation menu with items: System, Interfaces, Firewall, Services, VPN, and Status. Below the menu is a warning banner: "WARNING: The 'admin' account password is set to the default value. Change the password in the User Manager." The main content area is titled "Wizard / pfSense Setup / Time Server Information" and indicates "Step 3 of 9". The section is titled "Time Server Information" and contains the instruction: "Please enter the time, date and time zone." There are two input fields: "Time server hostname" with the value "0.pfsense.pool.ntp.org" and a sub-instruction "Enter the hostname (FQDN) of the time server.", and "Timezone" with a dropdown menu set to "America/Chicago". A blue "Next" button is located at the bottom of the form.

Fig. 5: Change the Timezone and Click Next



The screenshot shows the pfSense web interface. At the top, there is a navigation menu with items: System, Interfaces, Firewall, Services, VPN, Status, Diagnostics, and Help. Below the menu is a warning banner: "WARNING: The 'admin' account password is set to the default value. Change the password in the User Manager." The main content area is titled "Wizard / pfSense Setup / Configure WAN Interface" and indicates "Step 4 of 9". The section is titled "Configure WAN Interface" and contains the instruction: "On this screen the Wide Area Network information will be configured." There is a "SelectedType" dropdown menu set to "DHCP". Below this is a "General configuration" section with three input fields: "MAC Address" with a sub-instruction "This field can be used to modify ('spoof') the MAC address of the WAN interface (may be required with some cable connections). Enter a MAC address in the following format: xxx:xxx:xxx:xxx or leave blank.", "MTU" with a sub-instruction "Set the MTU of the WAN interface. If this field is left blank, an MTU of 1492 bytes for PPPoE and 1500 bytes for all other connection types will be assumed.", and "MSS" with a sub-instruction "If a value is entered in this field, then MSS clamping for TCP connections to the value entered above minus 40 (TCP/IP header size) will be in effect. If this field is left blank, an MSS of 1492 bytes for PPPoE and 1500 bytes for all other connection types will be assumed. This should match the above".

Fig. 6: Default Settings Should be Acceptable. Click Next

9. After a few seconds, a message will indicate the Setup Wizard has completed. To proceed to the pfSense dashboard, click `Finish`.
10. A final notification screen will appear stating that **NO COMMERCIAL DISTRIBUTION...** Click `Accept` to continue to the pfSense dashboard.



Fig. 7: Read and Click **Accept**

If you unplugged the Ethernet cable at the beginning of this configuration, reconnect it to the WAN port now.

This completes the basic configuration for the Netgate appliance.

1.3 pfSense Overview

This page provides an overview of the pfSense® dashboard and navigation. It also provides information on how to perform frequent tasks such as backing up the pfSense software and connecting to the Netgate firewall console.

1.3.1 The Dashboard

pfSense software is highly configurable, all of which can be done through the dashboard. This orientation will help to navigate and further configure the firewall.

Section 1 shows important system information such as the model, Serial Number, and Netgate Device ID for this Netgate firewall.

Section 2 identifies what version of pfSense software is installed, and if an update is available.

Section 3 describes Netgate Service and Support.

Section 4 shows the various menu headings. Each menu heading has drop-down options for a wide range of configuration choices.




Fig. 8: The pfSense Dashboard

1.3.2 Re-running the Setup Wizard

To re-run the Setup Wizard, navigate to **System -> Setup Wizard**.

1.3.3 Backup and Restore

It is important to backup the firewall configuration prior to updating or making any configuration changes. From the menu at the top of the page, browse to **Diagnostics > Backup/Restore**.

Click **Download configuration as XML** and save a copy of the firewall configuration to the computer connected to the Netgate firewall.

This backup (or any backup) can be restored from the same screen by choosing the backed up file under **Restore Configuration**.

Note: Auto Config Backup is a built-in service located at **Services -> Auto Config Backup**. This service will save up to 100 encrypted backup files automatically, any time a change to the configuration has been made. Visit the [Auto Config Backup](#) page for more information.




Fig. 9: Re-run the Setup Wizard




Fig. 10: Backup & Restore




Fig. 11: Click Download configuration as XML

Connecting to the Console

There are times when accessing the console is required. Perhaps GUI console access has been locked out, or the password has been lost or forgotten.

See also:

Connecting to the Console Port Connect to the console. Cable is required.

Tip: To learn more about getting the most out of your Netgate appliance, sign up for a [pfSense Training](#) course or browse our extensive [Resource Library](#).

1.4 Input and Output Ports

1.4.1 Front Side



Ethernet Ports

Interface Name	Port Name	Port Type	Port Speed
WAN	mvneta0.4090	RJ-45	1 Gbps
LAN	mvneta0.4091	RJ-45	1 Gbps
OPT	mvneta0.4092	RJ-45	1 Gbps

Note: The ethernet ports are switched and configured by default on their own VLAN, see the *Switch Overview* for more information.

Other Front Ports

- 1x USB 2.0 (left side)
- 1x USB 3.0 (right side)

1.4.2 Rear Side



From left to right:

1. Power Connector
 - 12VDC 2A Center Pin Positive
 - Power Consumption 3.48W (Idle)
2. Micro USB Console Port
3. Recessed Reset Button (performs a hard reset, immediately turning the system off)

Warning: A hard reset of the system *could* cause data corruption and should be avoided. Halt or reboot the system through the console menu or the webConfigurator to avoid data corruption.

1.4.3 Top Side

Table 1: Indicators

Status LED	State	Description
Black Diamond	Blink Fast	pfSense® boot in progress
	Solid	pfSense boot complete
	Blink Slow	pfSense software upgrade is available
Blue Square	Active	mPCIe activity (not supported)
Green Circle	Solid	Power

1.5 Safety and Legal

1.5.1 Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer

Warning: Do not use this product in location that can be submerged by water.

Warning: Do not use this product during an electrical storm to avoid electrical shock.

1.5.2 Electrical Safety Information

1. Compliance is required with respect to voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified may result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.
2. There are no operator serviceable parts inside this equipment. Service should be provided only by a qualified service technician.
3. This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.
 - a) Do not substitute the power cord with one that is not the provided approved type. If a 3 prong plug is provided, never use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.
 - b) The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.
 - c) Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment.
 - d) Protective grounding/earthing is provided by Listed AC adapter. Building installation shall provide appropriate short-circuit backup protection.
 - e) Protective bonding must be installed in accordance with local national wiring rules and regulations.

1.5.3 FCC Compliance

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment.

1.5.4 Industry Canada

This Class B digital apparatus complies with Canadian ICES-3(B). Cet appareil numérique de la classe B est conforme à la norme NMB-3(B) Canada.

1.5.5 CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.

1.5.6 RoHS/WEEE Compliance Statement

English

European Directive 2002/96/EC requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

Deutsch

Die Europäische Richtlinie 2002/96/EC verlangt, dass technische Ausrüstung, die direkt am Gerät und/oder an der Verpackung mit diesem Symbol versehen ist, nicht zusammen mit unsortiertem Gemeindeabfall entsorgt werden darf. Das Symbol weist darauf hin, dass das Produkt von regulärem Haushaltsmüll getrennt entsorgt werden sollte. Es liegt in Ihrer Verantwortung, dieses Gerät und andere elektrische und elektronische Geräte über die dafür zuständigen und von der Regierung oder örtlichen Behörden dazu bestimmten Sammelstellen zu entsorgen. Ordnungsgemäßes Entsorgen und Recyceln trägt dazu bei, potentielle negative Folgen für Umwelt und die menschliche Gesundheit zu vermeiden. Wenn Sie weitere Informationen zur Entsorgung Ihrer Altgeräte benötigen, wenden Sie sich bitte an die örtlichen Behörden oder städtischen Entsorgungsdienste oder an den Händler, bei dem Sie das Produkt erworben haben.

Español

La Directiva 2002/96/CE de la UE exige que los equipos que lleven este símbolo en el propio aparato y/o en su embalaje no deben eliminarse junto con otros residuos urbanos no seleccionados. El símbolo indica que el producto en cuestión debe separarse de los residuos domésticos convencionales con vistas a su eliminación. Es responsabilidad suya desechar este y cualesquiera otros aparatos eléctricos y electrónicos a través de los puntos de recogida que ponen a su disposición el gobierno y las autoridades locales. Al desechar y reciclar correctamente estos aparatos estará contribuyendo a evitar posibles consecuencias negativas para el medio ambiente y la salud de las personas. Si desea obtener información más detallada sobre la eliminación segura de su aparato usado, consulte a las autoridades locales, al servicio de recogida y eliminación de residuos de su zona o pregunte en la tienda donde adquirió el producto.

Français

La directive européenne 2002/96/CE exige que l'équipement sur lequel est apposé ce symbole sur le produit et/ou son emballage ne soit pas jeté avec les autres ordures ménagères. Ce symbole indique que le produit doit être éliminé dans un circuit distinct de celui pour les déchets des ménages. Il est de votre responsabilité de jeter ce matériel ainsi que tout autre matériel électrique ou électronique par les moyens de collecte indiqués par le gouvernement et les pouvoirs publics des collectivités territoriales. L'élimination et le recyclage en bonne et due forme ont pour but de lutter contre l'impact néfaste potentiel de ce type de produits sur l'environnement et la santé publique. Pour plus d'informations sur le mode d'élimination de votre ancien équipement, veuillez prendre contact avec les pouvoirs publics locaux, le service de traitement des déchets, ou l'endroit où vous avez acheté le produit.

Italiano

La direttiva europea 2002/96/EC richiede che le apparecchiature contrassegnate con questo simbolo sul prodotto e/o sull'imballaggio non siano smaltite insieme ai rifiuti urbani non differenziati. Il simbolo indica che questo prodotto non deve essere smaltito insieme ai normali rifiuti domestici. È responsabilità del proprietario smaltire sia questi prodotti sia le altre apparecchiature elettriche ed elettroniche mediante le specifiche strutture di raccolta indicate dal governo o dagli enti pubblici locali. Il corretto smaltimento ed il riciclaggio aiuteranno a prevenire conseguenze potenzialmente negative per l'ambiente e per la salute dell'essere umano. Per ricevere informazioni più dettagliate circa lo smaltimento delle vecchie apparecchiature in Vostro possesso, Vi invitiamo a contattare gli enti pubblici di competenza, il servizio di smaltimento rifiuti o il negozio nel quale avete acquistato il prodotto.

1.5.7 Declaration of Conformity

Česky[Czech]

NETGATE tímto prohlašuje, že tento NETGATE device, je ve shodě se základními požadavky a dále s ostatními ustanoveními směrnice 1999/5/ES.

Dansk [Danish]

Undertegnede NETGATE erklærer herved, at følgende udstyr NETGATE device, overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Nederlands [Dutch]

Hierbij verklaart NETGATE dat het toestel NETGATE device, in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG. Bij deze verklaart NETGATE dat deze NETGATE device, voldoet aan de essentiële eisen en aan de overige relevante bepalingen van Richtlijn 1999/5/EC.

English

Hereby, NETGATE , declares that this NETGATE device, is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Eesti [Estonian]

Käesolevaga kinnitab NETGATE seadme NETGATE device, vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Suomi [Finnish]

NETGATE vakuuttaa täten että NETGATE device, tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen. Français [French] Par la présente NETGATE déclare que l'appareil Netgate, device est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Deutsch [German]

Hiermit erklärt Netgate, dass sich diese NETGATE device, in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 1999/5/EG befindet". (BMW)

Ελληνικά [Greek]

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ ΝΕΤΓΑΤΕ ΔΗΛΩΝΕΙ ΟΤΙ ΝΕΤΓΑΤΕ device, ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΠΙΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1995/5/ΕΚ.

Magyar [Hungarian]

Alulírott, NETGATE nyilatkozom, hogy a NETGATE device, megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Íslenska [Icelandic]

Hér me l sír NETGATE yfir ví a NETGATE device, er í samræmi við grunnkröfur og a rar kröfur, sem ger ar eru í tilskipun 1999/5/EC.

Italiano [Italian]

Con la presente NETGATE dichiara che questo NETGATE device, è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Latviski [Latvian]

Ar o NETGATE deklar , ka NETGATE device, atbilst Direkt vas 1999/5/EK b tiskaj m pras b m un citiem ar to saist tajiem noteikumiem.

Lietuviškai [Lithuanian]

NETGATE deklaruoja, kad šis NETGATE įrenginys atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Malti [Maltese]

Hawnhekk, Netgate, jiddikjara li dan NETGATE device, jikkonforma mal- ti ijjiet essenzjali u ma provvedimenti o rajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Norsk [Norwegian]

NETGATE erklærer herved at utstyret NETGATE device, er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Slovensky [Slovak]

NETGATE t mto vyhlasuje, e NETGATE device, sp a základné po iadavky a v etky príslu né ustanovenia Smernice 1999/5/ES.

Svenska [Swedish]

Härmed intygar NETGATE att denna NETGATE device, står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Español [Spanish]

Por medio de la presente NETGATE declara que el NETGATE device, cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Polski [Polish]

Niniejszym, firma NETGATE o wiadcza, e produkt serii NETGATE device, spełnia zasadnicze wymagania i inne istotne postanowienia Dyrektywy 1999/5/EC.

Português [Portuguese]

NETGATE declara que este NETGATE device, está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Română [Romanian]

Prin prezenta, NETGATE declară că acest dispozitiv NETGATE este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivei 1999/5/CE.

1.5.8 Disputes

ANY DISPUTE OR CLAIM RELATING IN ANY WAY TO YOUR USE OF ANY PRODUCTS/SERVICES, OR TO ANY PRODUCTS OR SERVICES SOLD OR DISTRIBUTED BY RCL OR ESF WILL BE RESOLVED BY BINDING ARBITRATION IN AUSTIN, TEXAS, RATHER THAN IN COURT. The Federal Arbitration Act and federal arbitration law apply to this agreement.

THERE IS NO JUDGE OR JURY IN ARBITRATION, AND COURT REVIEW OF AN ARBITRATION AWARD IS LIMITED. HOWEVER, AN ARBITRATOR CAN AWARD ON AN INDIVIDUAL BASIS THE SAME DAMAGES AND RELIEF AS A COURT (INCLUDING INJUNCTIVE AND DECLARATORY RELIEF OR STATUTORY DAMAGES), AND MUST FOLLOW THE TERMS OF THESE TERMS AND CONDITIONS OF USE AS A COURT WOULD.

To begin an arbitration proceeding, you must send a letter requesting arbitration and describing your claim to the following:

Rubicon Communications LLC
Attn.: Legal Dept.
4616 West Howard Lane, Suite 900
Austin, Texas 78728
legal@netgate.com

The arbitration will be conducted by the American Arbitration Association (AAA) under its rules. The AAA's rules are available at www.adr.org. Payment of all filing, administration and arbitrator fees will be governed by the AAA's rules.

We each agree that any dispute resolution proceedings will be conducted only on an individual basis and not in a class, consolidated or representative action. We also both agree that you or we may bring suit in court to enjoin infringement or other misuse of intellectual property rights.

1.5.9 Applicable Law

By using any Products/Services, you agree that the Federal Arbitration Act, applicable federal law, and the laws of the state of Texas, without regard to principles of conflict of laws, will govern these terms and conditions of use and any dispute of any sort that might arise between you and RCL and/or ESF. Any claim or cause of action concerning these terms and conditions or use of the RCL and/or ESF website must be brought within one (1) year after the claim or cause of action arises. Exclusive jurisdiction and venue for any dispute or claim arising out of or relating to the parties' relationship, these terms and conditions, or the RCL and/or ESF website, shall be with the arbitrator and/or courts located in Austin, Texas. The judgment of the arbitrator may be enforced by the courts located in Austin, Texas, or any other court having jurisdiction over you.

1.5.10 Site Policies, Modification, and Severability

Please review our other policies, such as our pricing policy, posted on our websites. These policies also govern your use of Products/Services. We reserve the right to make changes to our site, policies, service terms, and these terms and conditions of use at any time.

1.5.11 Miscellaneous

If any provision of these terms and conditions of use, or our terms and conditions of sale, are held to be invalid, void or unenforceable, the invalid, void or unenforceable provision shall be modified to the minimum extent necessary in order to render it valid or enforceable and in keeping with the intent of these terms and conditions. If such modification is not possible, the invalid or unenforceable provision shall be severed, and the remaining terms and conditions shall be enforced as written. Headings are for reference purposes only and in no way define, limit, construe or describe the scope or extent of such section. Our failure to act with respect to a breach by you or others does not waive our right to act with respect to subsequent or similar breaches. These terms and conditions set forth the entire understanding and agreement between us with respect to the subject matter hereof, and supersede any prior oral or written agreement pertaining thereto, except as noted above with respect to any conflict between these terms and conditions and our reseller agreement, if the latter is applicable to you.

1.5.12 Limited Warranty

DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY

THE PRODUCTS/SERVICES AND ALL INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) AND OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH THE PRODUCTS/SERVICES ARE PROVIDED BY US ON AN "AS IS" AND "AS AVAILABLE" BASIS, UNLESS OTHERWISE SPECIFIED IN WRITING. WE MAKE NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, AS TO THE OPERATION OF THE PRODUCTS/SERVICES, OR THE INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) OR OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH THE PRODUCTS/SERVICES, UNLESS OTHERWISE SPECIFIED IN WRITING. YOU EXPRESSLY AGREE THAT YOUR USE OF THE PRODUCTS/SERVICES IS AT YOUR SOLE RISK.

TO THE FULL EXTENT PERMISSIBLE BY APPLICABLE LAW, RUBICON COMMUNICATIONS, LLC (RCL) AND ELECTRIC SHEEP FENCING (ESF) DISCLAIM ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. RCL AND ESF DO NOT WARRANT THAT THE PRODUCTS/SERVICES, INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) OR OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH THE PRODUCTS/SERVICES, RCL'S OR ESF'S SERVERS OR ELECTRONIC COMMUNICATIONS SENT FROM RCL OR ESF ARE FREE OF VIRUSES OR OTHER HARMFUL COMPONENTS. RCL AND ESF WILL NOT BE LIABLE FOR ANY DAMAGES OF ANY

KIND ARISING FROM THE USE OF ANY PRODUCTS/SERVICES, OR FROM ANY INFORMATION, CONTENT, MATERIALS, PRODUCTS (INCLUDING SOFTWARE) OR OTHER SERVICES INCLUDED ON OR OTHERWISE MADE AVAILABLE TO YOU THROUGH ANY PRODUCTS/SERVICES, INCLUDING, BUT NOT LIMITED TO DIRECT, INDIRECT, INCIDENTAL, PUNITIVE, AND CONSEQUENTIAL DAMAGES, UNLESS OTHERWISE SPECIFIED IN WRITING.

IN NO EVENT WILL RCL'S OR ESF'S LIABILITY TO YOU EXCEED THE PURCHASE PRICE PAID FOR THE PRODUCT OR SERVICE THAT IS THE BASIS OF THE CLAIM.

CERTAIN STATE LAWS DO NOT ALLOW LIMITATIONS ON IMPLIED WARRANTIES OR THE EXCLUSION OR LIMITATION OF CERTAIN DAMAGES. IF THESE LAWS APPLY TO YOU, SOME OR ALL OF THE ABOVE DISCLAIMERS, EXCLUSIONS, OR LIMITATIONS MAY NOT APPLY TO YOU, AND YOU MIGHT HAVE ADDITIONAL RIGHTS.

HOW-TO GUIDES

2.1 Connecting to the Console Port

There are times when directly accessing the console is required. Perhaps webGUI or SSH access has been locked out, or the password has been lost or forgotten. This guide shows how to regain access directly through the console.

2.1.1 Install the Driver

A **Prolific PL2303 USB-to-UART Bridge** driver is used to provide access to the console, which is exposed via the **Micro-USB B** port on the appliance.

If needed, install an appropriate **Prolific PL2303 USB to UART Bridge** driver on the workstation used to connect with the system.

Windows

There are drivers available for Windows [available for download](#).

Mac OSX

There are drivers available for Mac OSX [available for download](#).

For Mac, choose **Mac OS X Universal Binary Driver**.

Linux

There are drivers available for Linux [available for download](#).

Recent versions of many Linux distributions include this driver and will not require manual installation.

FreeBSD

Recent versions of FreeBSD include this driver and will not require manual installation.

2.1.2 Connect a USB Cable

Next, locate an appropriate USB cable that has a **Micro-USB B** connector on one end and a regular **USB Type A** plug on the other end. These cables are commonly used with smaller USB peripherals such as GPS units, cameras, and so on.

Gently push the **Micro-USB B** plug end into the console port on the appliance and connect the **USB Type A** plug into an available USB port on the workstation.

Tip: Be certain to gently push in the **Micro-USB B** connector on the system side completely. With most cables there will be a tangible “click”, “snap”, or similar indication when the cable is fully engaged.


2.1.3 Locate the Console Port Device

The appropriate console port device that the workstation assigned as the serial port must be located before attempting to connect to the console.

Note: Even if the serial port was assigned in the BIOS, the workstation’s OS may remap it to a different COM Port.

Windows

To locate the device name on Windows, open **Device Manager** and expand the section for **Ports (COM & LPT)**. Look for an entry with a title such as **Prolific USB-to-Serial Comm Port**. If there is a label in the name that contains “COMX” where X is a decimal digit (e.g. **COM3**), that value is what would be used as the port in the terminal program.



Mac OSX

The device associated with the system console is likely to show up as **/dev/cu.usbserial**.

Linux

The device associated with the system console is likely to show up as **/dev/ttyUSB0**. Look for messages about the device attaching in the system log files or by running `dmesg`.

Note: If the device does not appear in **/dev/**, see the note above in the driver section about manually loading the Linux driver and then try again.

FreeBSD

The device associated with the system console is likely to show up as **/dev/cuaU0**. Look for messages about the device attaching in the system log files or by running `dmesg`.

2.1.4 Launch a Terminal Program

Use a terminal program to connect to the system console port. Some choices of terminal programs:

Windows

For Windows it is recommended to run *PuTTY in Windows* or *SecureCRT*. An example of how to configure Putty is below.

Warning: Do not use **Hyperterminal**.

Mac OSX

For Mac OSX it is recommended to run *screen*, or *cu*. An example of how to configure screen is below.

Linux

For Linux it is recommended to run *screen*, *PuTTY in Linux*, *minicom*, or *dterm*. An example of how to configure Putty and screen is below.

FreeBSD

For FreeBSD it is recommended to run *screen* or *cu*. An example of how to configure screen is below.

Client-Specific Examples

PuTTY in Windows

Open PuTTY and select **Session** under **Category** on the left hand side. Next, set the **Connection type** to **Serial**. Then, set **Serial line** to the console port that was located above, in *Locate the Console Port Device*, and the **Speed** to 115200 bits per second.

Click the **Open** button and the console screen will be displayed.

PuTTY in Linux

Open PuTTY from a terminal by typing **sudo putty**. Next, set the **Connection type** to **Serial**. Then, set **Serial line** to **/dev/ttyUSB0** and the **Speed** to 115200 bits per second.

Click the **Open** button and the console screen will be displayed.

GNU screen

In many cases *screen* may be invoked simply by using the proper command line, where `<console-port>` is the console port that was located above.

```
sudo screen <console-port> 115200
```

If portions of the text are unreadable but appear to be properly formatted, the most likely culprit is a character encoding mismatch in the terminal. Adding the `-U` parameter to the *screen* command line arguments forces it to use UTF-8 for character encoding:

```
sudo screen -U <console-port> 115200
```




Fig. 1: An example of using PuTTY in Windows.



Fig. 2: An example of using PuTTY in Linux.

Terminal Settings

The settings to use within the terminal program are:

Speed 115200 baud, the speed of the BIOS

Data bits 8

Parity none

Stop bits 1

Flow Control Off or XON/OFF. Hardware flow control (RTS/CTS) must be **disabled**.

2.1.5 Troubleshooting

No Serial Output

If there is no output at all, check the following items:

- Ensure the cable is correctly attached and fully inserted
- Ensure the terminal program is using the correct port
- Ensure the terminal program is configured for the correct speed. The default BIOS speed is **115200**, and many other modern operating systems use that speed as well. Some older operating systems or custom configurations may use slower speeds such as **9600** or **38400**.
- Ensure the operating system is configured for the proper console (e.g. `ttys1` in Linux). Consult the various operating install guides on this site for further information.

PuTTY has issues with line drawing

PuTTY generally handles most cases OK but can have issues with line drawing characters on certain platforms.

These settings seem to work best (tested on Windows):

Window Columns x Rows = 80x24

Window > Appearance Font = *Courier New 10pt* or *Consolas 10pt*

Window > Translation Remote Character Set = *Use font encoding* or *UTF-8*

Window > Translation Handling of line drawing characters = *Use font in both ANSI and OEM modes*
or *Use Unicode line drawing code points*

Window > Colours Indicate bolded text by changing = The colour

Garbled Serial Output

If the serial output appears to be garbled, binary, or random characters check the following items:

- Ensure the terminal program is configured for the correct speed. (See *No Serial Output*)
- Ensure the terminal program is configured for the proper character encoding, such as **UTF-8** or **Latin-1**, depending on the operating system. (See *GNU Screen*)

Serial Output Stops After the BIOS

If serial output is shown for the BIOS but stops afterward, check the following items:

- Ensure the terminal program is configured for the correct speed for the installed operating system. (See *No Serial Output*)
- Ensure the installed operating system is configured to activate the serial console.
- Ensure the installed operating system is configured for the proper console (e.g. `ttys1` in Linux). Consult the various operating install guides on this site for further information.
- If booting from a USB flash drive, ensure that the drive was written correctly and contains a bootable operating system image.

2.2 Reinstalling pfSense Software

1. Please [open a support ticket](#) to request access to the factory firmware by selecting **Firmware Access** as the **General Problem** and then select **Netgate SG-1100** for the platform. Make sure to include the serial number in the ticket to expedite access.

Once the ticket is processed, the latest stable version of the firmware will be attached to the ticket, with a name such as:

```
pfSense-netgate-SG-1100-recovery-2.4.5-p1-RELEASE-aarch64.img.gz
```

Note: The pfSense® factory version is the version that is preinstalled on units purchased from Netgate. The factory image is optimally tuned for our hardware and contains some features that cannot be found elsewhere, such as the AWS VPN Wizard.

2. Write the image to a USB memstick. Locating the image and writing it to a USB memstick is covered in detail under [Writing Flash Drives](#).
3. *Connect to the console port* of the Netgate device.
4. Insert the memstick into the USB port and boot the system.

Tip: Best practice is to **turn off** the system, **insert** the USB memstick, ensure you have **console access**, and **reboot** the system. You will need to **interrupt the boot process** very soon after initial boot.

5. When prompted, press any key to stop the autoboot process.

```
NOTICE: BL2: Built : 16:19:45, Nov  1 20NOTICE: BL31: v1.3(release):armada-17.
10.8:34247e0
NOTICE: BL31:

U-Boot 2017.03-armada-17.10.2-g6a6581a-dirty (Nov 01 2018 - 16:04:57 -0300)

Model: Marvell Armada 3720 Community Board ESPRESSOBin
   CPU      @ 1200 [MHz]
   L2       @ 800  [MHz]
   TClock   @ 200  [MHz]
   DDR      @ 750  [MHz]
DRAM:  1 GiB
U-Boot DT blob at : 0000000003f716298
Comphy-0: USB3           5 Gbps
Comphy-1: PEX0           2.5 Gbps
Comphy-2: SATA0         6 Gbps
SATA link 0 timeout.
AHCI 0001.0300 32 slots 1 ports 6 Gbps 0x1 impl SATA mode
flags: ncq led only pmp fbss pio slum part sxs
PCIE-0: Link down
MMC:   sdhci@d0000: 0, sdhci@d8000: 1
SF: Detected mx25u3235f with page size 256 Bytes, erase size 64 KiB, total 4 MiB
Net:   eth0: neta@30000 [PRIME]
Hit any key to stop autoboot:  2
```

6. Type `run usbrecovery` at the **Marvell>>** prompt and press Enter.
7. Select the destination device by pressing Enter, then confirm by pressing `y` and Enter.

Note: The onboard eMMC flash memory is always `mmc0`.

8. Wait for the installation to the eMMC to complete.
9. Once the install has completed, remove the memstick, and cycle the power (unplug the SG-1100 and plug it back in) to reboot the SG-1100.

Note: For information on restoring from a previously saved configuration, go to [Backup and Restore](#).

```
Welcome to pfSense 2.4.4-RELEASE1...

Netgate SG-1100 firmware recovery
Serial:
Netgate Crypto ID:

This will install the standard firmware and will erase all the existing
contents of the destination device permanently.

eMMC device: mmc0

Type the name of the destination device (mmc0) or type enter to install on mmc0:

Selected eMMC device: mmc0

Are you sure you want to continue ? (y/N) y

Erasing the eMMC contents...
Writing the firmware to eMMC...
(this may take a few minutes to complete)
```

```
FreeBSD/arm64 (pfSense-sg1100-recovery) (ttyu0)

May 16 10:46:48 pfSense-sg1100-recovery shutdown: halt by root:
Stopping cron.
Waiting for PIDS: 521.
Stopping devd.
Waiting for PIDS: 318.
Writing entropy file:.
Writing early boot entropy file:.
Terminated
.
May 16 10:46:51 pfSense-sg1100-recovery syslogd: exiting on signal 15
Waiting (max 60 seconds) for system process `vnlru' to stop... done
Waiting (max 60 seconds) for system process `bufdaemon' to stop... done
Waiting (max 60 seconds) for system process `syncer' to stop...
Syncing disks, vnodes remaining... 1 0 0 done
All buffers synced.
Uptime: 2m46s


The operating system has halted.
Power cycle or reset to reboot.
```

2.3 Configuring a Router on a Stick

This optional guide shows the steps required to configure all three VLANs on one port. In this example we will use the OPT port.

Note: Performing this configuration from the LAN port will help prevent us from being locked out. Also, the WAN and LAN ports will still work with untagged devices connected to them. The LAN port could be used as a management port. In normal operation, the switch would only need to be connected to OPT, with WAN and LAN disconnected.

1. Connect to the LAN port on the SG-1100.
2. From the pfSense® webGUI menu, navigate to **Interfaces > Switches**.



3. Go to the **VLANs** tab.
4. Click on the  button for **VLAN group 3**.

Warning: **VLAN group 0** must remain in place and **VLAN groups 1-3** must include **0t** as a member, in order to function properly.

Interfaces / Switch / Ports ?

System Ports **VLANs**

SG-1100 Switch Ports

Port #	Port name	Port VID	LAGG	Flags	State	Media	Status
0	LAN Uplink	1	-	HOST	FORWARDING	Ethernet 1000baseT <full-duplex>	Active
1	OPT	4091	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
2	LAN	4091	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
3	WAN	4090	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier

 Save

Interfaces / Switch / VLANs ?

System Ports **VLANs**

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
 If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	
	1	4090	0t,3	WAN	 
	2	4091	0t,2	LAN	 
	3	4092	0t,1	OPT	 

 Save
  Add Tag
  Edit

5. Check **tagged** for **Member 1**, then click **Save**.

Interfaces / Switch / VLANs / Edit

Vlan properties

VLAN tag

Enter a VLAN ID number (that is not already in use.)

Description

A description may be entered here for administrative reference (not parsed).

Member(s)	Tagged	Action
<input type="text" value="0"/>	<input checked="" type="checkbox"/> tagged	
<input type="text" value="1"/>	<input checked="" type="checkbox"/> tagged	

6. Click on the button for **VLAN group 2**.
7. Click on the **Add member** button, Enter Member 1, check **tagged** and then click **Save**.
8. Click on the button for **VLAN group 1**.
9. Click on the **Add member** button, Enter Member 1, check **tagged** and then click **Save**.
10. Click on the **Ports** tab.
11. Click on the **Port VID** for **OPT**. Change the default value 4092 to 1. In the lower right-hand corner click **Save**.

When completed the Ports and VLANs configuration should reflect the screenshots below:

You can now connect a managed switch (VLANs 4090-4092 must be trunked on the switchport of the managed switch) to OPT with VLANs 4090 (WAN), 4091 (LAN), and 4092 (OPT) tagged to it.

If you need access to the WebConfigurator on LAN, you can just connect a laptop to LAN and you should receive a DHCP lease (unless DHCP Server on LAN has been disabled). You will also be able to access the WebGUI (unless the default Anti-Lockout Rule has been disabled) and internet (unless the Default allow LAN to any rule has been disabled).

Interfaces / Switch / VLANs ?

System Ports VLANs

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	
	1	4090	0t,3	WAN	
	2	4091	0t,2	LAN	
	3	4092	0t	OPT	

Edit

Save Add Tag

Interfaces / Switch / VLANs / Edit ?

Vlan properties

VLAN tag ▼
Enter a VLAN ID number (that is not already in use.)

Description 📄
A description may be entered here for administrative reference (not parsed).

Member(s)	Tagged	Action
<input type="text" value="0"/>	<input checked="" type="checkbox"/> tagged	Delete
<input type="text" value="2"/>	<input type="checkbox"/> tagged	Delete
2 <input type="text" value="1"/>	<input checked="" type="checkbox"/> tagged	3 Delete

4 Save Add member 1

Interfaces / Switch / VLANs ?

System Ports VLANs

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
 If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	
	1	4090	0t,3	WAN	
	2	4091	0t,1t,2	LAN	
	3	4092	0t,1t	OPT	

Save Add Tag

Interfaces / Switch / VLANs / Edit ?

Vlan properties

VLAN tag

Enter a VLAN ID number (that is not already in use.)

Description

A description may be entered here for administrative reference (not parsed).

Member(s)	Tagged	Action
<input type="text" value="0"/>	<input checked="" type="checkbox"/> tagged	Delete
<input type="text" value="3"/>	<input type="checkbox"/> tagged	Delete
2 <input type="text" value="1"/>	<input checked="" type="checkbox"/> tagged	3 Delete

4 Save Add member 1

Interfaces / Switch / VLANs ?

System **Ports** VLANs

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
 If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	
	1	4090	0t,1t,3	WAN	
	2	4091	0t,1t,2	LAN	
	3	4092	0t,1t	OPT	

Save + Add Tag

Interfaces / Switch / Ports ?

System **Ports** VLANs

SG-1100 Switch Ports

Port #	Port name	Port VID	LAGG	Flags	State	Media	Status
0	LAN Uplink	1	-	HOST	FORWARDING	Ethernet 1000baseT <full-duplex>	Active
1	OPT	4092	-		FORWARDING	Default (no preference, typically autoselect) v	No Carrier
2	LAN	4091	-		FORWARDING	Default (no preference, typically autoselect) v	No Carrier
3	WAN	4090	-		FORWARDING	Ethernet autoselect (1000baseT <full-duplex> Default (no preference, typically autoselect) v	Active

Save

Interfaces / Switch / VLANs ?

System Ports **VLANs**

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	
	1	4090	0t,1t,3	WAN	
	2	4091	0t,1t,2	LAN	
	3	4092	0t,1t	OPT	

Save Add Tag

Interfaces / Switch / Ports ?

System Ports VLANs

Port settings updated. ×

SG-1100 Switch Ports							
Port #	Port name	Port VID	LAGG	Flags	State	Media	Status
0	LAN Uplink	1	-	HOST	FORWARDING	Ethernet 1000baseT <full-duplex>	Active
1	OPT	1	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
2	LAN	4091	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
3	WAN	4090	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier

 Save

2.4 Installing the Wallmount Kit

This page shows how to install the optional SG-1100 Wall Mount Kit.

Tip: Save the SG-1100 MAC Address, Serial Number, and NDI, located on the bottom of the system, before attaching the SG-1100 to the wall.




Fig. 3: Loop one side of the Silicone Band under the wall mount of the SG-1100

Note: Remove the rubber standoff feet from the SG-1100 prior to attaching to the wall mount. Do **not** remove the screws that are under the rubber standoff feet.

Tip: Remember to save the SG-1100 MAC Address, Serial Number, and NDI, located on the bottom of the system, before attaching the SG-1100 to the wall.

Hang the wall mount with the cables hanging down. Secure the cables to the holes on the wall mount with cable ties to relieve the weight from the ports.





Fig. 4: Stretch the Silicone Band to the opposite side of the wall mount






Fig. 5: Loop the silicone band under the opposite side of the wall mount




Fig. 6: The silicone band should look like this




Fig. 7: Tuck both sides of the silicone band under the wall mount



Fig. 8: Place the SG-1100 over the silver aluminum standoffs on the wall mount and pull one side of the silicone band over the SG-1100, then the other



Fig. 9: When mounted properly, the SG-1100 should look like this



Fig. 10: Note the silicone band under the SG-1100 when installed correctly




Fig. 11: An SG-1100 wall mount kit correctly installed

2.5 Configuring the Switch Ports

This optional guide shows the steps required to configure the LAN and OPT ethernet ports to be on the same VLAN.

Note: When connecting to the webConfigurator, be sure you are NOT connected to the port you are going to configure or you will lose connectivity during this procedure.


1. Open the pfSense® WebGUI and log in.
2. From the menu, navigate to **Interfaces > Switches**.



3. Go to the **Ports** sub-menu.
4. Click on the **Port VID** for **OPT**. Change the default value from 4092 to 4091. In the lower right-hand corner click **Save**.

At this point **Interfaces > Switches > Ports** should look like the following:

5. Click on the **VLANs** tab.
6. Click on the  button for **VLAN group 3**.



The screenshot shows the pfSense web interface. At the top, there is a navigation bar with the pfSense logo and three dropdown menus: 'System', 'Interfaces', and 'Firewall'. Below the navigation bar, a red warning box contains the text: 'WARNING: The 'admin' account password is set to the default value'. Underneath the warning, a breadcrumb trail reads 'Interfaces / Switch / System'. Below the breadcrumb, there are three tabs: 'System', 'Ports', and 'VLANs'. The 'Ports' tab is highlighted with a red circle. Below the tabs, a dark grey header reads 'Switch System'. Underneath this header is a table with the following data:

Type	Ports	VLAN groups
Marvell 6000 series switch	6	128

Interfaces / Switch / Ports ?

System Ports VLANs

SG-1100 Switch Ports

Port #	Port name	Port VID	LAGG	Flags	State	Media	Status
0	LAN Uplink	1	-	HOST	FORWARDING	Ethernet 1000baseT <full-duplex>	Active
1	OPT	4092	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
2	LAN	40	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
3	WAN	4090	-		FORWARDING	Ethernet autoselect (1000baseT <full-duplex> Default (no preference, typically autoselect) ▼	Active

 Save

Warning: VLAN group 0 must remain in place and VLAN groups 1-3 must include 0t as a member, in order to function properly.

7. Click **Delete** for **Member 1**, then click **Save**.
8. Click on the  button on **VLAN group 2**.
9. Click on the **Add member** button. Enter Member 1, uncheck **tagged** and then click **Save**.
10. Confirm the configuration matches the screenshots below:

Note: Unlike software bridging, traffic between ports 1 and 2 will never leave the switch chip so it will perform at switching speed. You also cannot filter traffic between the two ports as pfSense will never see it, just like with any other (external) switch.

Interfaces / Switch / Ports ?

System Ports VLANs

Port settings updated. x

SG-1100 Switch Ports							
Port #	Port name	Port VID	LAGG	Flags	State	Media	Status
0	LAN Uplink	1	-	HOST	FORWARDING	Ethernet 1000baseT <full-duplex>	Active
1	OPT	4091	-		FORWARDING	Default (no preference, typically autoselect) v	No Carrier
2	LAN	4091	-		FORWARDING	Default (no preference, typically autoselect) v	No Carrier
3	WAN	4090	-		FORWARDING	Default (no preference, typically autoselect) v	No Carrier

 Save

Interfaces / Switch / Ports ?

System Ports **VLANs**

SG-1100 Switch Ports

Port #	Port name	Port VID	LAGG	Flags	State	Media	Status
0	LAN Uplink	1	-	HOST	FORWARDING	Ethernet 1000baseT <full-duplex>	Active
1	OPT	4091	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
2	LAN	4091	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier
3	WAN	4090	-		FORWARDING	Default (no preference, typically autoselect) ▼	No Carrier

 Save

Interfaces / Switch / VLANs ?

System Ports **VLANs**

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
 If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	
	1	4090	0t,3	WAN	 
	2	4091	0t,2	LAN	 
	3	4092	0t,1	OPT	 

 Save
 Add Tag
 Edit

Interfaces / Switch / VLANs / Edit ?

Vlan properties

VLAN tag ⬆ ⬇ ⬆
 Enter a VLAN ID number (that is not already in use.)

Description 📄
 A description may be entered here for administrative reference (not parsed).

Member(s)

<input type="text" value="0"/>	<input checked="" type="checkbox"/> tagged	🗑 Delete
<input type="text" value="1"/>	<input type="checkbox"/> tagged 1	🗑 Delete

2
📄 Save
+ Add member

Interfaces / Switch / VLANs ?

System Ports **VLANs**

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
 If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	🔗
	1	4090	0t,3	WAN	🔗 🗑
	2	4091	0t,2	LAN	🔗
	3	4092	0t	OPT	🔗

Edit

📄 Save
+ Add Tag

Interfaces / Switch / VLANs / Edit ?

Vlan properties

VLAN tag ▼
 Enter a VLAN ID number (that is not already in use.)

Description 📄
 A description may be entered here for administrative reference (not parsed).

Member(s)

<input type="text" value="0"/>	<input checked="" type="checkbox"/> tagged	🗑 Delete
<input type="text" value="2"/>	<input type="checkbox"/> tagged	🗑 Delete
2 <input type="text" value="1"/>	3 <input type="checkbox"/> tagged	🗑 Delete

4 📄 Save + Add member 1

Interfaces / Switch / VLANs ?

System Ports VLANs

SG-1100 Switch 802.1Q VLANs

Enable Enable 802.1q VLAN mode
 If enabled, packets with unknown VLAN tags will be dropped.

VLAN(s) table	VLAN group	VLAN tag	Members	Description	Action
	0	1	0	Default System VLAN	✎
	1	4090	0t,3	WAN	✎ 🗑
	2	4091	0t,1,2	LAN	✎ 🗑
	3	4092	0t	OPT	✎ 🗑

📄 Save + Add Tag

Interfaces / Switch / Ports ?

System Ports VLANs

SG-1100 Switch Ports

Port #	Port name	Port VID	LAGG	Flags	State	Media	Status
0	LAN Uplink	1	-	HOST	FORWARDING	Ethernet 1000baseT <full-duplex>	Active
1	OPT	4091	-		FORWARDING	Default (no preference, typically autoselect) ▾	No Carrier
2	LAN	4091	-		FORWARDING	Default (no preference, typically autoselect) ▾	No Carrier
3	WAN	4090	-		FORWARDING	Ethernet autoselect (1000baseT <full-duplex> Default (no preference, typically autoselect) ▾	Active

 Save

REFERENCES

3.1 Additional Resources

3.1.1 Netgate Training

Netgate training offers training courses for increasing your knowledge of pfSense® products and services. Whether you need to maintain or improve the security skills of your staff or offer highly specialized support and improve your customer satisfaction; Netgate training has got you covered.

<https://www.netgate.com/training>

3.1.2 Resource Library

To learn more about how to use your Netgate appliance and for other helpful resources, make sure to browse our Resource Library.

<https://www.netgate.com/resources>

3.1.3 Professional Services

Support does not cover more complex tasks such as CARP configuration for redundancy on multiple firewalls or circuits, network design, and conversion from other firewalls to pfSense software. These items are offered as professional services and can be purchased and scheduled accordingly.

<https://www.netgate.com/our-services/professional-services.html>

3.1.4 Community Options

If you elected not to get a paid support plan, you can find help from the active and knowledgeable pfSense community on our forums.

<https://forum.netgate.com/>

3.2 Warranty and Support

- One year manufacturer's warranty (optional second year warranty available at time of purchase only).
- Please contact Netgate for warranty information or view our [Product Lifecycle](#) page.
- All Specifications subject to change without notice

For support information, view our [support plans](#).

See also:

For more information on how to use pfSense® software, see the [pfSense Documentation and Resource Library](#).